


Fairbanks® Scales

Ultra Low Power Instrument
Models H90-3051
H90-3051C1 – H90-3051C4




SJ4321 / Issue #4

Table of Contents

SECTION 1: DESCRIPTION OF EQUIPMENT	1
1.1 Introduction	1
1.2 General Description	1
1.3 Customer/Operator Responsibilities	1
1.4 Specifications/Design Features	1
1.5 Accessories	3
SECTION 2: GENERAL INSTALLATION PROCEDURES	6
2.1 General Service Policy	6
2.2 Pre-Installation Checklist	6
2.3 Unpacking	7
2.4 Instrument Location	7
2.5 Printer/Remote Display Installation	7
2.6 Safety	7
SECTION 3: PRINTER SET-UP	8
3.1 Introduction	8
SECTION 4: OPERATIONS	10
4.1 Introduction and Overview	10
4.2 Instrument Controls	10
4.3 Instrument Weighing Functions	11
4.4 Entering ID's	13
4.5 Setpoint Requirements	13
4.6 Grading Scale Mode	14
4.7 Setpoint Operation	14
4.8 Lbs/Gallons Operation and Programming	19
4.9 4-20mA Current Output Operation	19
4.10 Digital Output Operation	20
SECTION 5: FUNCTION KEY PROGRAMMING	22
5.1 "PASS" Prompt	22
5.2 Test Mode (Program Code, A/D Counts, and Display Test)	22
5.3 Time	22
5.4 Date	23
5.5 Asleep	23
5.6 Setpoints	23
5.7 Grading Scale	24
5.8 Printer Output Channel A	25
5.9 Computer/Remote Display Output (Channel B)	26
5.10 Analog Output (4-20mA)	27
SECTION 6: CUSTOMER/OPERATOR SERVICE	30
6.1 Basic Maintenance and Troubleshooting	30
6.2 Periodic Inspection Procedures	30
6.3 Battery Packs 575 and 575D	31
<i>APPENDIX I: CONTROL DRAWINGS</i>	<i>32</i>
<i>APPENDIX II: ASCII CHARACTER TO NUMERIC VALUES</i>	<i>36</i>
<i>APPENDIX III: OUTPUT FORMATS</i>	<i>37</i>
<i>APPENDIX IV: CANADIAN STANDARD ASSOCIATION APPROVED INSTRUMENTS</i>	<i>38</i>

DISCLAIMER

Every effort has been made to provide complete and accurate information in this manual. However, although this manual may include a specifically identified warranty notice for the product, Fairbanks Scales makes no representations or warranties with respect to the contents of this manual, and reserves the right to make changes to this manual without notice when and as improvements are made to the product.



ULPI Model H90-3051 Front Panel

SECTION 1: DESCRIPTION OF EQUIPMENT

1.1 Introduction

The information in this Section provides a general description of the product, customer/operator responsibilities, technical specifications/features, safety and lists various accessories available for the product.

WARNING

For Factory Mutual Approved Installation in hazardous areas see control drawing 3-56060 in Appendix III included in this manual.

1.2 General Description

Fairbanks Low Power Series Digital Instruments, H90-3051, are designed to function as weight indicating and control elements of electronic or electro-mechanical (Levetronic) weighing systems. The Instrument converts the analog weight signal from the Load Receiver to digital display and output data.

Major features of the Low Power Series include pushbutton programming/calibration and an alphanumeric status display. Microprocessor-controlled weight conversion circuits allow the Instrument to be rapidly programmed at installation to meet the specific requirements of the application.

1.3 Customer/Operator Responsibilities

Do not break the seals on the instrument or attempt any internal adjustments. It is the customer/operators' responsibility to maintain the platform, instrument, and peripheral Accessories provided by Fairbanks in good order, and to protect the equipment from accidental or malicious damage. Other than the procedures authorized in Section 6 "Instrument Service", no service, repair, or adjustment may be performed by untrained personnel.

1.4 Specifications/Design Features

A. Technical Specifications

1. Capacities:
Up to 500,000 lb, kg, oz, g, ton, tonne, or lbs-to-gallon conversion
2. Division Sizes:
Service Programmed for 0.00001 to 200
3. Resolution/Accuracy:
Up to 10,000 divisions maximum in commercial applications
Up to 20,000 divisions maximum in non-commercial applications

Accuracy - meets Handbook H-44 requirements
4. Sensitivity:

1 microvolt/division
Maximum signal input: 3mV/V

5. Rounding:
Nearest division (0.5 division rounded upwards), per NIST H-44.
6. Display:
 - a. High contrast liquid crystal numerals
 - b. 6 active digits; 5 active digits with minus sign
 - c. 7 segment, 1.25" high, Decimal points
 - d. Center-of-Zero legend
 - e. Weighing mode legends and any required prompts
 - f. Various displays that will light up giving the operator an indication of which function the instrument is in.
7. Rezero Range:
2% or 100% of capacity, service programmable.
8. Display Update Rate:
Service programmable 0.3, 0.5, 0.8 or 1.0 seconds
9. Out of Weight Range Warning:
 - a. Overcapacity Warning:
When the gross weight exceeds the capacity by 5% or more, the instrument will indicate an overload condition by displaying "-----".
 - b. Underload Warning:
Displays "-----" if weight on platform is below the instruments operating range.
10. Auto Zero Tracking (AZT):
Compensates for gradual buildup of material on the load receiver. Service-programmable for OFF, ± 0.6 , 1.0, or 3.0 divisions.
11. Warm-Up Time:
Warm-up approximately 10 seconds; displays "-init-" during warm-up.
12. Radio Frequency Interference (RFI):
Protected against RFI radiation.
13. Motion Detection:
Programmable for 0.6, 1.0, 2.0, 3.0 divisions.
14. Calibration Program Protection:
100% retention of calibration/programming data in nonvolatile EEPROM.
15. Outputs (Accessories required):
 - a. Setpoint Accessory #584 and #5804 provide 2 and 4 outputs respectively for use in controlling alarms, gates, etc. Refer to Section 5 for details.
 - b. The SMART 4-20 mA Accessory #5810 is driven by either the net or gross weight or by the output

from the instruments A/D converter. Refer to Section 5 for details.

- c. Printer/Remote Display Data Output is only available when Interface Accessories #5805, #5806, #5807 and #5808 are included in installation. Refer to Sections 5 and 6 and Appendix V for details.
16. Load Cell Excitation:
8 volts pulsed; passing through current limiting resistors.
17. Load Cell Cable Length:
Use only shielded Cable as specified below.
 - a. Single or multiple load cells, up to 25 feet of cable without sense leads - use Fairbanks cable #701125.
 - b. Single or multiple load cells, up to 500 feet of cable with sense leads - use Fairbanks cable #701025.
18. Load Cells:
Up to 4 - 350 ohm; 8 - 750/1000 ohm cells
19. Sleep Mode:
Two "Battery Saver" functions for maximum battery life.
 - a. Instrument can be programmed to automatically shut-off after a period of time if no Instrument functions are used.
 - b. Instrument can be manually turned OFF by pushing the **FUNC** and then **SLEEP** key.
20. Battery Life:
Battery Life is affected by the load on the Instrument excitation circuit, the Sleep Mode function and the accessories used.

B. Requirements

The following requirements apply to the Instrument only. If Accessories are interfaced, consideration must be given to any further limitations or requirements described in the particular device's Instruction Manual.

1. Power Requirements:
Power - Battery Pack, Accessory #575, supplied with Instrument or Accessory #575D (dual battery pack)

NOTE

For hazardous area installations, Battery Pack must be removed to safe area for recharging or may be trickle charged in the hazardous areas through the use of accessories.

2. Grounding Auxilliary Equipment:
Any auxilliary equipment (e.g. 5800 accessory) connected to an AC line (117 VAC \pm 10%; 50/60 Hz, \pm 0.5 HZ) must be connected to a grounded powerline having maximum 3.0 ohms resistance to true earth ground. Instrument chassis should be connected to true earth ground.
3. Environment:
 - a. Temperature:
Operating -10°C (14°F) to $+40^{\circ}\text{C}$ (104°F)
Maximum change rate $\pm 10^{\circ}\text{C}$ (20°F)/hour

Storage: -40°C (-40°F) to $+60^{\circ}\text{C}$ (140°F)
 - b. Relative Humidity: 0% to 100%, Suitable for water wash-down

1.5 Accessories

The H90-3051 is compatible with the Fairbanks Accessories described below.

NOTE

Accessories can be installed in hazardous areas where specifically indicated. For hazardous area installations, some Accessories must be located in safe area except where otherwise indicated.

A. Interface Accessory #5800

A NEMA 4x, water-tight/dust tight corrosion resistant box installed in a safe area, is required:

1. to house Accessories 5804, 5811, and 584.
2. to provide trickle charge for all battery accessories.
3. to provide power to instrument when used with Accessory 5810 or 5814.

Dimensions $15\frac{1}{2}'' \times 14'' \times 6\frac{3}{8}''$.

B. Battery Pack Accessory #575/575D

These corrosion resistant rechargeable Battery Pack Accessories provide 8.0 VDC to the Instrument and are the **only** batteries to be used with the Low Power Instruments and may be installed in hazardous areas.

1. Cycle Life
Battery can be recharged from 200 to 2000 times dependent on depth of discharge. Approximately 200 cycles at 100% discharge when LobAtt is displayed or 2000 cycles at 25%. A recharge schedule which would prevent the battery from becoming completely discharged is therefore recommended. It is recom-

mended that the recharging of the batteries be as frequent as is practical.

2. Battery Storage

Spare batteries or Instruments should be stored in a cool place to prevent battery self-discharge. At 40°C the battery will self discharge in 5 months, as compared to 20 months at 20°C . Batteries can be stored to temperatures to -40°C .

3. Battery Charging

Charging time is 12 hours for fully discharged battery, Accessory 575, or 24 hours for Accessory 575D. A fully charged battery will read approximately 8.6 VDC (open circuit) at 20°C .

C. AC Adapter Accessory #579

This Accessory will convert 117VAC to DC for use by the Instrument. Depending on how it is used, it may also supply a trickle charge for the battery. **It cannot be used in a hazardous area.**

The Accessory may be used in one of the following two ways. This option is suggested where the Instrument will be continuously in the ON state, and Accessory 5800 is not in place.

1. In a safe area application, it can be plugged directly into the battery jack (J2) on the bottom of the Instrument.
2. In a safe area application, it can be plugged into the Analog Output Connector (J3) on the bottom of the Instrument. The Accessory will provide power for the Instrument and supply a trickle charge for the battery (assuming Accessory 5810 or 5814 is used).

D. Interface Cable Accessory #576

Cable required for interface from the hazardous area Instrument to the safe area 5800 Interface Box. The maximum length must not exceed 500 feet in hazardous applications.

E. SMART 4-20mA Accessory #5810

This Accessory is installed in the H90-3051 instrument and will provide the following outputs when used with Interface Accessory #5800:

1. 4-20mA analog current output. For more information see Section 5, Analog Outputs.
2. This accessory is necessary to operate Setpoint Accessory 584 or 5804.
3. Trickle charge for the instrument

F. Setpoints Accessory #584 and #5804

Two or four user selectable setpoints, Accessory #584 and #5804 are available. Accessory 5810, 5800 and 5811 must be installed with the setpoint accessories in hazardous locations. Grading scale operations do not require any accessories. Accessories 584 or 5804 are installed in the 5800 Interface Box located in a safe area.

G. Single Set of Safe Area Intrinsic Barriers Accessory #5811

Required for hazardous environment applications. There are two barriers per set. Installed in Accessory 5800. They are the connection between hazardous and safe areas.

H. Safe Area Battery Recharger Accessory #578

Replaced by Accessory 5815. This Accessory is used to recharge Battery Pack Accessory #575 or 575D and must be used only in the safe area. The accessory has no over-charge protection. It can only be used for 12 hours on a fully discharged 575 Battery Accessory or 24 hours on a fully discharged 575D Battery Accessory.

I. Battery Float Output Assembly #5814

Adapter located within the H90-3051 which enables the instrument to be trickle charged via the Interface Accessory #5800 in hazardous area applications or Accessory #579 in safe area applications without the need for a SMART 4-20mA Accessory.

J. Serial Communications Assembly #5805

This accessory is installed in the H90-3051 instrument and provides dual bi-directional fiber optic digital output board for interface to Accessory 5808.

K. Fiber Optic Cable #5806

Furnished in 25 feet multiples. One cable is required for each digital output. Maximum length is 150 feet. Contact Inquiry for longer distances.

L. One Pair Fiber Optic Digital Cable Connectors #5807

Required for each digital output of the H90-3051 and must be used with Accessory 5806.

M. Fiber Optic/RS232/Current Loop Transceiver #5808

Required for each digital output of the H90-3051. Bi-directional translator to convert Fiber Optics to RS232 20mA Current Loop signals.

N. 19" Rack Mount Adapter #5813

Replaces the front panel of the instrument and allows the instrument to be mounted in a standard 19" rack.

O. Interface Accessory #580

NEMA 4X, water-tight/dust-tight corrosion resistant box. Interface box is required when analog data interface to instrument is required. Battery trickle charge which continually recharges battery is included within this accessory. (Dimensions 15 $\frac{1}{2}$ " x 14" x 6 $\frac{3}{8}$ "). Refer to SJ4328 for further information. Replaced by Accessory 5800.

P. Smart Charger Accessory #5815

This accessory is a safe area battery charger which will provide overnight charging of a battery and then switch to a trickle charge mode to maintain full charge on the battery.

Q. Power Supply Accessory #5816

This accessory is an explosion proof junction box containing a conduit seal and a power supply. It is intended for use in all hazardous area locations except Group A and B locations. It is designed to be used in place of Battery Accessory 575.

Figure 2-1, on the following page, shows some of the relationships between the H90-3051 and the various accessories.




FIGURE 2-1
ACCESSORY FLOW CHART

SECTION 2: GENERAL INSTALLATION PROCEDURES

2.1 General Service Policy

Prior to installation, it must be verified that the equipment will satisfy the customer's requirements as supplied, and as described in this manual. If the equipment cannot satisfy the application and the application cannot be modified to meet the design parameters of the equipment, the installation should not be attempted.

The complete installation consists of:

1. Verifying application
2. Unpacking
3. Instrument checkout
4. Customer and site readiness:
 - a. Is Location ready?
 - b. Is Load Receiver ready?
 - c. Is the customer aware there will be work disruptions?
 - d. Is operator available for training?
5. Making Platform connections
6. Doing Calibration and Adjustments
7. Doing Customer training

NOTICE

A. *These instructions apply to the instrument only; installation procedures for Printers and other Accessories are given in Manuals specifically provided for those units. The instructions include a pre-installation checkout, which must be performed, either at the Service Shop before the Technician goes to the site, or at the site before he places the equipment on-line.*

B. *All electronic and mechanical calibrations and/or adjustments required to make this equipment perform to accuracy and operational specifications are considered to be part of the installation charge. Only those charges which are incurred as a result of the equipment's inability to be adjusted or calibrated to performance specifications may be charged to warranty.*

C. *Absolutely no physical, electrical or program modifications other than selection of standard options and Accessories are to be made to this equipment. Electrical connections other than those specified may not be performed, and no physical alterations (mounting holes, etc.) are allowed.*

D. *The installing Technician is responsible to make certain that personnel are fully trained and familiar with the equipment's capabilities and limitations before he considers the installation complete.*

2.2 Pre-Installation Checklist

The following points should be checked and discussed with the Field Engineer and/or Customer if necessary before the Technician goes to the site to install the equipment.

- Has the customer's application been checked to make certain that it is within the capabilities and design parameters of the equipment?
- If the installation will disrupt the customer's normal operations, is he aware and has he made arrangements?
- Is properly-grounded power available at the installation location?
- Will the equipment operator(s) be available for training?

- Has the Service Technician thoroughly reviewed the installation procedures?
- Has the Service Technician reviewed the recommended set-up with the Field Engineer or "Request for Service", and identified all necessary variations to satisfy the customer's particular application?

2.3 Unpacking

1. Check that all components and Accessories are on hand, and agree with the customer's order.
2. Remove all components from their packing material, checking to make certain that all parts are accounted for and no parts are damaged. Advise the shipper immediately if damage has occurred. Order any parts necessary to replace those which have been damaged. Keep the shipping container and packing material for future use. Check the packing list.
3. Collect all necessary installation manuals for the instrument and accessories.
4. Open the Instrument:
 - a. Using a $\frac{5}{16}$ " nut driver, loosen (but do not remove) the 4 screws along the bottom of the Front Panel.
 - b. Remove the remaining six screws from around the Front Panel.
 - c. Carefully tilt the Front Panel out from the enclosure.
5. Perform an inspection, making certain that all hardware, electrical connections and PC Assemblies are secure. Do not reinstall cover if final installation is to be performed after the pre-installation checkout.

2.4 Instrument Location

The Instrument should be positioned away from direct sunlight which would make the display difficult to read.

2.5 Printer/Remote Display Installation

Interface of a standard Fairbanks Printer or Remote Display requires the installation of Accessories #5805, #5806, #5807, and #5809. Refer to Fiber Optic Output Accessory Manual (SJ4326), and to the appropriate Printer or Remote Display Service Manual for set-up and programming procedures.

2.6 Safety

As is the case with any material handling equipment, certain safety precautions should be observed during operation:

1. Never load the platform beyond its rated capacity. Refer to the rating on the serial number plate if in doubt.
 2. Ensure that any structure which supports the platform is capable of withstanding the weight of the platform plus its rated capacity load.
 3. Do not load the platform if there is any evidence of damage to the platform or supporting structure.
 4. Use safety chains or other suitable restraining devices if there is any possibility of the load shifting, falling, or rolling from its position on the load receiver.
 5. Do not leave the platform unattended when it is loaded.
-

SECTION 3: PRINTER SET-UP

3.1 Introduction

Programming the instrument outputs allows the instrument to be used with various printers and/or remote displays. This Section describes the procedures to setup a selected printer.

The Customer may have a Security Code that must be entered to enable Customer/Operator programming.

The following printers may be interfaced to the H90-3051 Series Instrument. The switch settings are furnished to aid in setting up these printers.

1. Interface to a Fairbanks Model 50-3920 Form Printer:

Using the Printer Handbook, included with the printer, set the printer internal switches per the following tables:

Switch on Controller PCB								
Function	1	2	3	4	5	6	7	8
ASCII - US	ON	OFF	OFF					
11" Form Length				OFF	ON			
No Auto LF						OFF		
8 Bit Data							ON	
Not Used *								OFF
* Must remain in the OFF Position								

Switch on Serial Interface PCB								
Function	1	2	3	4	5	6	7	8
Busy Signal (SSD)	ON							
Baud Rate (2400)		ON	OFF	ON				
Not Used *					OFF			
Parity (8 Bit System)						ON		
Pin 20 Busy (DTR)							OFF	
Not Used *								OFF
* Must remain in the OFF position								

1a. Interface to a Fairbanks Model 50-3921 Serial Printer

Using the Printer Handbook included with the printer set the printer internal switches per the following table:

Function	Switch block on Controller PCB/Switch #							
	1	2	3	4	5	6	7	8
Ascii; slashed 0	OFF	OFF	OFF					
Form Length: 11 inches				OFF	ON			
Auto Line Feed: OFF						OFF		
Data Bits: 8							ON	
Front Panel: Enabled								OFF

Function	Switch Block # 1 on Super Speed Serial Board/Switch #							
	1	2	3	4	5	6	7	8
Parity: Odd	OFF							
Without Parity		ON						
Data Bits: 8			ON					
Protocol: Ready/Busy				ON				
Test Select: Circuit					ON			
Mode Select: Print						ON		
Busy Line; DTR "—" Pin # 20							ON	ON

Function	Switch Block # 2 on Super Speed Serial Board/Switch #							
	1	2	3	4	5	6	7	8
2400 Baud	OFF	OFF	ON					
DSR Input Signal: Inactive				OFF				
Buffer Threshold: 256 Bytes					OFF			
Buffer Signal Timing: 200MS (Min)						ON		
DTR Signal: Space After Power On							ON	
* Not Used								OFF
* Must remain in "OFF" position								
** The printer will work only if the Busy H option is selected when programming the outputs								

2. Interface to a Fairbanks Model 50-3710 Tape Printer:

Using the manual included with the Printer, set the printer internal switches per the following tables:

Printer Switch 1										
Function	1	2	3	4	5	6	7	8	9	10
7 or 8 Bit Data	OFF	OFF								
Parity Check			ON							
Even/Odd Parity				ON						
Stop Bit Length					ON					
RS232						ON				
TTL							OFF			
20mA Current Loop								OFF		
Right Home Position									OFF	
24 Column										OFF

Printer Switch 2							
Baud Rate	1	2	3	4	5	6	7
9600	OFF						
4800		OFF					
2400			ON				
1200				OFF			
600					OFF		
300						OFF	
150							OFF

3. Interface to a Fairbanks 50-3925 Ticket Printer. Set the switches on bottom of printer to the following:

9 Position Switch	
Open	Closed
1, 4, 5, 6	2, 3, 7, 8, 9

4. Interface to a Fairbanks 50-3715 Tape Printer. Set the switches on bottom of printer to the following:

8 Position Switch	
DS1	DS2
6 ON	2, 6, 7 ON
All others OFF	1, 3, 4, 5, 8 OFF

SECTION 4: OPERATIONS

4.1 Introduction and Overview

This Section describes operating procedures for the Low Power Instrument, H90-3051, when connected to a standard load receiver.

The operator should have a thorough understanding of the control functions and methods before attempting to operate this equipment.

Instructions apply to the instrument only. Refer to appropriate Accessory Manuals for their instructions.

4.2 Instrument Controls

This subsection provides a specific functional description of all instrument controls and indicators. Some control functions may be disabled as a result of service-programmed parameters.

A. Instrument Inhibits

Some of the instrument functions (zeroing, printing, etc.) will be inhibited if the instrument detects any of the following conditions:

- i. Motion on the platform
- ii. Underload
- iii. Overload
- iv. Out of re-zero range

B. Front Panel Keys

The functions of the front panel keys vary depending on the mode in which the instrument is operated. This Subsection defines the operation of each front panel key when in the weighing mode.




FIGURE 4-1: FRONT PANEL CONTROLS

ZERO

1. In Gross or Net Mode, this key will set the Gross weight equal to zero, if no inhibits are active.
 - a. If motion exists, the ZERO command will be retained and executed once the weight has stabilized.
 - b. If the weight on the platform exceeds the zero limit and the ZERO key is pressed, the ZERO command will not be executed, nor will it be saved in memory.
 - c. If the instrument is in the NETmode and the ZERO key is pressed, the instrument will automatically revert to the gross mode and the ZERO command will be executed.

AUTO
TARE

2. In Gross or Net Mode, this key will set Tare memory equal to the Gross weight on the Platform. The instrument will display "0" weight and enter the Net Weigh Mode. The NET Legend will be ON. Auto Tare will only operate if no inhibits are active and the Gross weight is positive.

UNITS

3. This key will toggle the displayed weight between the units that were selected in the Service Program e.i. kg to lb or lb to kg.

PRINT

4. This key is used to transmit weight data to an external device.

GROSS
NET

5. This key toggles between the Gross and Net Weigh Modes. If the instrument is in the Tare Mode, it will change to the Net Mode.

START

6. This key is used to initiate the set-point operation.

TRIM

7. This key is used to override the setpoint cycle and to add weight in touch controlled increments.

8. **STOP**
This key terminates the setpoint cycle. Also, it is used to select desired setpoint for subsequent setpoint operation.
9. **ID**
This key is used to enter a 6-digit numeric ID for printer/computer printout.
10. **TARE
RECALL**
This key displays the current Tare value for 5 seconds.
11. **ENTER**
This key enters Tare data.
12. **FUNC**
This key gives access to the special function keys; time, date, setpoint, program, test, and sleep
13. Numeric Keys
Keys **0** through **9** and **.** are used to enter Tares.
14. Displays
Displays weight on load receiver.




FIGURE 4-2: LEGENDS AND INDICATORS

15. Legends
There are 25 legends that can be displayed. While most are self explanatory, the following need some definition:
- CZ** Center of Zero
 - RECHARGE**
Battery power is low and will need to be recharged soon. The RECHARGE legend appears when the input voltage to the instrument (either from a battery or through a barrier) falls below a threshold of approximately 7.8 volts.
 - LOW BATT**
Battery requires immediate recharging. The

LOWBATT legend appears (and the RECHARGE legend disappears) when the voltage falls below approximately 7.0 volts. The instrument will also shut itself OFF leaving a blank display except for the LOWBATT legend.

d. **TOTAL** (Not Used)

16. Indicators
There are four indicators that show that specific setpoints are active.



C. Input-Output Connections




FIGURE 4-3: BOTTOM OF INSTRUMENT CASE

- J1**
Load receiver cable input connector.
- J2**
Battery power input connector.
- J3**
Analog output connector to Accessory #5800 Interface Box for use with Fairbanks Accessories. J3 is part of either Accessory 5810 or Accessory 5814.
- Fiber Optic Output Connectors**
Two 9-pin fiber optic connectors for output of printer or remote display data using channels "A" and "B". These connectors are part of Accessory 5805.

4.3 Instrument Weighing Functions

The industry uses three terms which describe the apportionment of an object's weight. These terms are GROSS WEIGHT, TARE WEIGHT, and NET WEIGHT.



Gross weight is the total weight of an object. This would include any incidental materials as well as the primary materials which comprise the object. Tare weight is the weight of the incidental materials. Net weight is the weight of the primary materials. Tare weight and Net weight together equal the Gross weight. A can of house paint is an object to be weighed. The can is incidental material used to hold the primary material, paint, and the label is incidental material used to identify the paint. All of the incidental materials' taken together make up the tare weight. All of the primary materials' weights together make up the Net weight; in this case pigment, vehicle, and solvent. The object is made up of incidental materials, can and label, and primary material, paint. Taken together, this is the gross weight.

The three weights can be expressed mathematically in terms of each other as follows:


$$\begin{aligned} \text{GROSS} &= \text{NET} + \text{TARE} \\ \text{TARE} &= \text{GROSS} - \text{NET} \\ \text{NET} &= \text{GROSS} - \text{TARE} \end{aligned}$$


The equation, $\text{NET} = \text{GROSS} - \text{TARE}$, is particularly important because it is the equation that a scale uses to figure net weights in NET WEIGHING MODE. The gross weight is a function of the weight on the platform and the zero reference. Tare weight is always an operator defined value.


A. Basic Weighing

1. Press the  key to select Gross as indicated by the legend.
2. With the platform empty, press the  key. The display will indicate zero and the Center-of-Zero legend will appear.
3. Place the object to be weighed on the platform.
4. The weight will be displayed.

The instrument is only able to measure the weight on the platform. The instrument can not tell if the weight is from the object to be weighed or from some other objects left on the platform. The operator must tell the scale when there is nothing on the platform to be weighed. This is

done by pressing the  key. The instrument will assign whatever weight happens to be on the platform a zero weight value. This is called the instrument's zero reference.


Starting with an empty platform is not required. The  key sets the display to "0", regardless of what is on the platform. Weighing in the Gross mode consists of


pressing the  key and placing a weight on the platform. The display will show the Gross weight of the object. The instrument understands Gross weight as the

total weight placed on the platform after the  key was pressed.


B. Tare Weights

The tare weight is operator defined. There are two ways to tell the instrument a tare weight to use. The first is to simply enter the tare value by the keyboard. This is called a keypad tare. The tare materials would have had to have been previously weighed so the operator would know

what value to enter. The  key is the second way to enter tare values. If the tare weight is not known, then the operator has to weigh the tare materials. While the tare weight is displayed, the operator can avoid entering

the displayed weight by pressing the  key. This will enter the displayed weight as a tare value.



The tare weight value will remain unaltered in memory until:

1. Power is removed.
2. The  key is pressed.
3. A new tare weight is entered via the keypad.
4. The Service Program mode is accessed.



If the value of the tare weight entered via the keypad does not correspond to an exact division size, the number will first be truncated to the correct decimal location and then rounded to the nearest division size, ie. for a division size of .1 an entered tare of 2.19 is truncated to 2.1 and then rounded to a final tare of 2.1. For a division size of 20 an entered tare of 511 will be truncated to 510 and then rounded to a final tare of 520.

Correct entry errors by entering "0's" until a single "0" is displayed.

C. Net Weighing Using The Keypad Tare

1. Enter the known tare weight of the empty carrier using the numeric keys. The instrument will automatically enter the Tare mode.
2. Push  to select the Net Mode. The display will indicate a negative net value equal to the tare in memory.
3. Place the loaded carrier on the platform and read the Net weight at the display.
4. Repeat Step 3 for carriers of the same Tare.
5. Repeat from Step 1 for carriers of a different Tare.
6. To read Gross weight, push  to select Gross.
7. When the load is removed from the platform, the display will indicate a negative net value equal to the tare in memory.

D. Net Weighing Using AUTO TARE

1. Press the  key. The display will read "0" and the GROSS Legend will be ON.
2. Place the empty carrier on the platform.
3. Press the  key. The display will show "0" and the NET Legend will be ON. The weight of the container on the platform will be entered into the scales memory as a Tare weight.
4. Place the material to be weighed in the container. The display will show the weight of the material in the container. This is the net weight.





NOTE

Net weighing of pre-packaged carriers can be accomplished by first placing an empty carrier that is the same as the product carrier on the



platform, and pushing  before beginning weighing operations.

E. Batching Using AUTO TARE

1. Select the Gross Mode and place the empty carrier on the platform. The display indicates the Tare.

2. Push .
3. Fill the carrier with the first item until the desired weight is achieved. Instrument display indicates the net weight of the first item (Mode is in GROSS).
4. Push  to reset the display to zero. Instrument display indicates zero net weight.
5. Place the next item into the carrier until the desired weight has been met.
6. Repeat Steps 4 and 5 until all items have been put into the carrier.
7. Switch to Gross and read the total net weight of the batch.
8. Repeat Steps 1 through 7 for other batches.
9. To clear the operation:
 - a. Select the Gross Mode.
 - b. Remove all material from the platform.
 - c. Push  to zero the display.
 - d. Push  to reset.
 - e. Select Gross Mode.

4.4 Entering ID's

1. Place the instrument into the weighing mode.
2. Press  key. The current ID number and ID legend will be displayed.
3. Use the numeric keypad to enter a new ID number 0 through 999999.
4. Press the  key to save the displayed ID number and return the instrument to the weighing mode.

The ID number will be printed as part of each print cycle if selected in function key programming.

4.5 Setpoint Requirements

A. Hardware Requirements

1. Operation of setpoints require accessories 5810, 5800 and 5804 (Quad Setpoint) or 584 (Dual Setpoint) to be installed.

NOTE

The "Grading Scale" mode does not require these accessories.

4.5.1 Service Requirements

- At the time of installation, one of nine setpoint options must have been selected at Service Program Step 14.

Programming Step 14 (Setpoints)			
Subsection	Code	Option	
5.7.A.1	1	Acc 584	Independent Setpoints, Zero Start
5.7.A.2	2	Acc 584	Independent Setpoints, Zero End
5.7.B.1	3	Acc 584	Paired Setpoints, Zero Start
5.7.B.2	4	Acc 584	Paired Setpoints, Zero End
5.6	5	Grading Scale	
5.7.B.1	6	Acc 5804	Paired Setpoints, Zero Start
5.7.B.2	7	Acc 5804	Paired Setpoints, Zero End
5.7.A.1	8	Acc 5804	Independent Setpoints, Zero Start
5.7.A.2	9	Acc 5804	Independent Setpoints, Zero End

These codes will be referred to in the Setpoint Operation, Section 5.6

A. User Setpoint And Grading Scale Programming Requirements

User Setpoint and Grading Scale Programming is done according to directions given in Section 5, Function Key Programming.

4.6 Grading Scale Mode

NOTE

The ACC 5804 will not function in a Grading application. ACC 584 must be used.

A. General Instructions

In the Grading Scale Mode, the setpoint option is used to operate the "Under", "Over", and "Accept" legends on the front panel of the instrument.

In this mode, Setpoint 1 is the lower Accept limit and Setpoint 2 is the upper Accept limit. Setpoints 3 and 4 are not used.

- "UNDER" is ON when the displayed weight is less than the Setpoint 1 value.
- "OVER" is ON when the displayed weight is greater than the Setpoint 2 value.

- "ACCEPT" is ON when the displayed weight is greater than or equal to the Setpoint 1 value but less than or equal to the Setpoint 2 value.

The Grading Scale option is functional in both Gross and Net Modes but only for positive weight displays.

The Grading Scale will not function if:

- the weight on the platform is outside the weighing range,
- the instrument is not in the weighing mode, or
- a negative weight is displayed



The START, STOP, and TRIM keys are disabled in the Grading Scale Mode.

B. Accessory 584

Accessory 584 can be used to provide dual relay outputs in the Grading Scale Mode.

The Setpoint 1 relay is energized if the displayed weight is less than the Setpoint 1 value. This is the same range as for the "Under" legend on the display.



The Setpoint 2 relay will de-energize if the displayed weight is greater than the Setpoint 2 value. This is the same range as for the "Over" legend on the instrument display.

The "Accept" range is represented when setpoint 1 relay is de-energized and the Setpoint 2 relay is energized.

	Acc 584 Relay State		
	Under	Accept	Over
Setpoint 1 Relay	E	D	D
Setpoint 2 Relay	E	E	D
D = De-energized E = Energized			

Both Setpoint Relay 1 and 2 will be in the energized state under the following conditions:

- the weight on the platform is outside the weighing range,
- the instrument is not in the weighing mode, or
- a negative weight is displayed

If Accessory 584 is installed, pressing the  STOP or  key will momentarily de-energize the relays.

4.7 Setpoint Operation

A setpoint is a user defined weight value placed in the instrument's memory to trigger the opening or closing of a relay.

A setpoint cycle begins when the **START** key is pressed and terminates when the weight on the platform reaches the setpoint value contained in the instrument's memory, or the **STOP** key is pressed.

The instrument can have up to 4 setpoint values stored in memory called "Setpoints 1, 2, 3, and 4". The operator must indicate to the instrument which setpoint is to be used in the current weighing cycle. The operator must step through the setpoint indicators by repeatedly pressing the **STOP** key. The step sequence will be:

Setpoints disabled

Setpoint 1 selected

Setpoint 2 selected

* Setpoints 1 and 2 selected

Setpoint 3 selected

Setpoint 4 selected

* Setpoints 3 and 4 selected

* This selection will only appear when paired setpoint operation has been selected in program step 14. Paired setpoint operation pairs Setpoints 1 and 2 together and Setpoints 3 and 4 together.

When the desired setpoint indicator is lighted, the setpoint operation can proceed.




FIGURE 4-4: SETPOINT INDICATOR LOCATIONS

The setpoint cycle will terminate and all setpoint relays will reset, de-energize in Accessory 5804 or energize in Accessory 584 under the following conditions:

- When not in the weighing mode
- When the scale is showing under or over capacity

c. Operation of any key other than the **START** key.

All the setpoints operate in both Gross or Net modes and positive or negative displayed weights.

A. Independent Setpoints

The **STOP** key will terminate the setpoint cycle at any point after the **START** key has been pressed.

If the **TRIM** key is pressed when no setpoint cycle is in operation, it will change the polarity of the setpoint relay.

This change will remain in effect until the **TRIM** key is released. If a setpoint cycle is in operation, pressing and releasing the **TRIM** key will terminate the cycle.

1. SINGLE SETPOINT, Zero Start, codes 1 or 8

Setpoint Range

When a value is assigned to a single setpoint, a weight range is defined. The weight range is 0 plus and minus the setpoint value.

Mode Code

A code number is chosen to relate the START weight to the setpoint range. If a 1 or an 8 is selected, the START weight must be inside the setpoint range.

Operation

- With a setpoint range defined, place a weight on the platform that falls within the range.
- Press the **START** key. The setpoint cycle is initiated and the relay will change polarity. The weight on the platform can be changed until the setpoint weight is reached, at which time the polarity of the relay will reverse and the setpoint cycle is terminated.
- If the weight on the platform is outside the setpoint range, NOTHING will happen if the **START** key is pressed and nothing will happen if the weight on the platform is changed.




FIGURE 4-5: ACCESSORY 5804




FIGURE 4-6: ACCESSORY 584

2. SINGLE SETPOINT, Zero End, codes 2 or 9

Setpoint Range

When a value is assigned to a setpoint, a weight range is defined. The weight range is 0 plus and minus the setpoint value.

Mode Code

A code number is chosen to relate the START weight to the setpoint range. If a 2 or a 9 is selected, the START weight must be outside the setpoint range.

Operation

1. With a setpoint range defined, place a weight on the platform that falls outside the range.
2. Press the **START** key. The setpoint cycle is initiated and the relay will change polarity. The weight on the platform can be changed until the setpoint weight is reached, at which time the polarity of the relay will reverse, and the setpoint cycle is terminated.
3. If the weight on the platform is inside the setpoint range, NOTHING will happen if the **START** key is pressed and nothing will happen if the weight on the platform is changed.




FIGURE 4-7: ACCESSORY 5804




FIGURE 4-8: ACCESSORY 584

B. PAIRED SETPOINTS

The key will terminate the setpoint cycle at any point after the key has been pressed.

If the key is pressed when no setpoint cycle is in operation, the polarity of Setpoint 2 relay is changed.

When the key is released, the polarity of Setpoint 2 relay will return to its original state.

If the key is pressed during a setpoint cycle, the Setpoint 1 relay will reset. The Setpoint 2 relay will not respond. When the key is released, Setpoint 2 relay will change polarity, and the cycle will be terminated.

1. PAIRED SETPOINTS, Zero Start, Code 3 Or 6, With Setpoint 1 And 2 Selected Or Setpoint 3 And 4 Selected

NOTE

Paired Setpoints 3 and 4 work the same as paired Setpoints 1 and 2.

In this mode the setpoints are paired in the setpoint cycle. A weight value is assigned to setpoint 1 and another value is assigned to Setpoint 2. When the setpoint cycle is

initiated by pressing the key each setpoint changes the polarity of the relay it controls. When the weight on the platform reaches the first setpoint value, the setpoint changes the polarity of the relay. When the weight reaches the second setpoint value, it changes the polarity of its relay and the cycle is terminated.

Setpoint Range

When a weight value is assigned a setpoint, a weight range is defined. The weight range is zero, plus and minus the setpoint value.

The Setpoint 1 value must be smaller than the Setpoint 2 value.

Mode Code

A code number is chosen to relate the START weight to the setpoint range. If a code of 3 or 6 is selected, the start weight must be inside the Setpoint 1 range.

Operation

1. With the setpoint ranges defined, place a weight on the platform that is within the Setpoint 1 range.
2. Press the key. This initiates the setpoint cycle and the relays will change polarity. When the weight on the platform reaches the Setpoint 1 value, relay 1 will change its polarity. When the weight on the platform reaches the Setpoint 2 value, the second relay will change its polarity and the cycle will terminate.

A setpoint cycle is only terminated when the Setpoint 2 weight value is achieved. Until the cycle is terminated by Setpoint 2, the setpoint 1 relay will respond to weight changes that pass through Setpoint 1 range limits.

If the weight on the platform is beyond the Setpoint 2 range, nothing happens when the key is pressed and nothing will happen if the weight on the platform is changed.




FIGURE 4-9: ACCESSORY 5804




FIGURE 4-10: ACCESSORY 584

2. PAIRED SETPOINTS, Zero End, Code 4 Or 7, With Setpoints 1 And 2 Selected Or Setpoints 3 And 4 Selected.

In this mode the setpoints are paired in the setpoint cycle. A weight value is assigned to setpoint 1 and another value is assigned to Setpoint 2. When the setpoint cycle is

initiated by pressing the **START** key each setpoint changes the polarity of the relay it controls. When the weight on the platform reaches the first setpoint value, the setpoint changes the polarity of the relay. When the weight reaches the second setpoint value, it changes the polarity of its relay and the cycle is terminated.

Setpoint Range

When a weight value is assigned a setpoint, a weight range is defined. The weight range is zero, plus and minus the setpoint value.

The Setpoint 1 value must be greater than the Setpoint 2 value.

Mode Code

A code number is chosen to relate the START weight to the setpoint range. If a code of 3 or 6 is selected, the start weight must be outside the setpoint 1 range.

Operation

1. With the setpoint range defined, place a weight on the platform that is outside the Setpoint 1 range.

2. Press the **START** key. Both relays will change polarity. When the weight on the platform reaches the Setpoint 1 value, relay 1 will change its polarity. When the weight on the platform reaches the Setpoint 2 value, the second relay will change its polarity and the cycle will terminate.

A setpoint cycle is only terminated when the Setpoint 2 weight value is achieved. Until the cycle is terminated by Setpoint 2, the setpoint 1 relay will respond to weight changes that pass through Setpoint 1 range limits.

If the weight on the platform is inside the Setpoint 2 range,

nothing happens when the **START** key is pressed and nothing will happen if the weight on the platform is changed.




FIGURE 4-11: ACCESSORY 5804




FIGURE 4-12: ACCESSORY 584

3. PAIRED SETPOINTS, Code 3, 4, 6, Or 7, With Only Setpoints 1 Or 3 Selected.

Setpoint Range

When a weight value is assigned a setpoint, a weight range is defined. The weight range is zero, plus and minus the setpoint value.

Operation

1. Press the key to initiate the operation.
2. As weight is added or removed from the platform, the setpoint relay changes polarity each time the weight value passes the setpoint value.
3. The operation may be ended at any time by pressing the or the key.




FIGURE 4-13: ACCESSORY 5804




FIGURE 4-14: ACCESSORY 584

4. Paired Setpoints, Code 3, 4, 6 or 7 With Only Setpoints 2 or 4 Selected

See "Independent Setpoints".

4.8 Lbs/Gallons Operation and Programming

A. Operation

1. The gallons unit of measure is available as a net weighing function only.
 - a. When pressing the UNITS key to select "gal" (gallons), the instrument will also enter the net weighing mode.
 - b. When printing or transmitting to a remote display, the gallons data will be available in the net weight data field.
2. When displaying "Gallons"
 - a. The "Tare Recall" and "SETPOINT" programming functions are not available in this mode.
 - b. The "Auto Tare" key will enter the weight on the platform into tare memory and exit to the "NET" "Lb" mode.

B. Programming The Conversion Factor

This procedure describes changing the lb/gal conversion factor. At no time is the conversion factor available for viewing after the initial entry.

1. Select the "gallons" display mode by pressing the UNITS key.
2. Use the numeric keypad to enter a conversion factor, then press ENTER key. A conversion factor up to 6 digits may be entered. The conversion factor must be greater than 5 and must be entered as lbs/gal.

Correct entry errors by entering "0's" until a single "0" is displayed.

If the keyboard tare function has been disabled, ie. program Step 8 has been set to "0", gallons conversion factor programming will also be disabled. The current conversion factor will be retained in memory.

4.9 4-20mA Current Output Operation

The 4-20mA Analog Output requires Accessory 5810 and 5800 and Service Program Step 13 enabled. The information programmed at Service Step 13 determines if the output current is directly (current increases with increasing weight) or inversely (current decreases with increasing weight) proportional to the weight on the platform.

Condition

Output

- | | |
|---------------------------------|---------------------------------------------------------------|
| 1. Out of Weighing Range | 24mA |
| 2. ASLEEP Mode | 0mA |
| 3. LobAtt | 0mA |
| 4. All other non-weighing modes | remains at last value just prior to exiting the weighing mode |




FIGURE 4-15: GROSS WEIGH MODE




FIGURE 4-16: NET WEIGH MODE

4.10 Digital Output Operation

A. Channel A, Printers

See Appendix III or typical output formats.

1. Data available to be printed

Gross weight
Tare weight
Net weight
Time
Date
ID

This data cannot be formatted, however the above data items can be enabled or disabled for printing. See Function Key Programming, Channel A.

2. The data will be transmitted over Channel A each time

the key is pressed if there is no motion on the platform and a valid weight is displayed, ie. not out of weighing range or in a non-weighing mode. "ACK" legend will appear momentarily.

- If the key is pressed during an inhibit condition, printing will not occur once the inhibiting condition ends. The key will have to be pressed again.

B. Channel B, Computers

See Appendix III for output protocol.

- If continuous output was selected, see Function Key Programming, Channel B, the displayed weight will be transmitted at the display update rate.
- Pressing the key will inhibit transmission to the computer until transmission over Channel A is complete.
- If polled output was selected, see Function Key Programming, Channel B, the displayed weight will be transmitted each time the instrument is polled. If the key is pressed, Channel A output data will be transmitted on Channel B.

C. Channel B, Remote Displays

See Appendix III for output protocol.

- The displayed weight will be transmitted at the display update rate.
- Pressing the key will inhibit transmission to the remote display until transmission over Channel A is complete.

SECTION 5: FUNCTION KEY PROGRAMMING

When programming setpoints, grading scale, and 4-20mA analog output current, the weight values entered must be in the same units as were displayed just prior to exiting the weighing mode.

All of the following programming parameters use the

FUNC key as part of the programming step. If the **FUNC** key is inadvertently pressed, it is possible to

return to the Weigh mode by pressing the **FUNC** key again.

5.1 "PASS" Prompt

All **FUNC** key operations can be protected by an

Access Code to prevent unauthorized entry to **FUNC** key operations. When "PASS" appears in the display, the operator must enter the correct Access Code and press

ENTER in order to continue. If "PASS" is displayed, it is

possible to return to the Weigh mode by pressing **ENTER**. The Access Code is assigned during Service

Programming. To correct entry errors, press **0** until a single zero is displayed.

5.2 Test Mode (Program Code, A/D Counts, and Display Test)

FUNC **8 TEST**

This program enables the operator to check each of the display segments and operator legend prompts for proper operation.

1. Select the Gross or Net Mode.

2. Press the **FUNC** key then the **8 TEST** key. Display will show A/D counts.

3. Instrument will display in the following sequence when the **ENTER** key is pushed:

- a. Program code, "P189", followed by a revision letter
 - b. All segments and status indicators
4. Instrument will return to the Gross or Net Mode

5.3 Time

FUNC **4 TIME**

Accessory 5805 must be installed before the time function will operate.

1. From a gross or net weight display, press **FUNC**.

The display will indicate "FunC".

2. Press **4 TIME** key.

3. The display will indicate a time (e.g. "11:36") with the AM or PM legend ON. If the time was initially set in military format (00:00 thru 23:59), the AM or PM legends will not be shown.

NOTE

If Accessory #5805 was *not* installed, then the time display will be " : : : : " .

4. Press **ENTER** if time is correct. The instrument will return to the weigh mode. If the time is incorrect, press any numeric key **0** through **9** to clear the display. ("PASS" may appear at this time. Take appropriate action.)

5. Enter the correct time by pressing the numeric keys **0** through **9**. Enter the hours first and then the minutes. Both hours and minutes must be entered as two digit numbers. To enter the time 8:05, enter "08" then "05".

6. To select the time format, press the **4 TIME** key.

The following legends will be displayed in sequence.

AM (Standard Time)
PM (Standard Time)
No AM or PM Legend (Military Time)

7. When the desired format is displayed, press the



key to store the format and displayed time.

5.4 Date



NOTE

The year **must** be reset each January 1st and the day **must** be reset every February 29th.

Accessory 5805 must be installed before the date function can be used.

1. From a gross or net weight display, press

The display will indicate "Func".

2. Press the key and a date and date legend will be displayed.

The display will show a date e.g. "12:30:89". If the "ACK" legend is lit, the date is in international format.

Standard format – MM:DD:YY
International format – DD:MM:YY

NOTE

If Accessory #5805 was **not** installed, then date display will be "----:----:----".

3. Press if the date is correct. The instrument will return to the weight display.

4. Press any key through to clear the display.

5. Enter the date by pressing the numeric keys through .

Enter the date as day/month/year or month/day/year format.

All entries must be two digit numbers. To enter June 1, 1991, use 06, 01, 91.

6. With the ACK legend turned off, the entered date will be stored in the month/day/year format.

To change format, press the key. The ACK legend will light.

The following legends will be displayed in sequence.

ACK legend OFF (month/day/year format)

ACK legend ON (day/month/year format)

7. When the correct date and format is displayed, press the key to store the displayed date and format.

5.5 Asleep



The instrument can enter the "ASLEEP" Mode either automatically or manually to conserve battery power.

To put the instrument asleep manually:

1. From a gross or net weight display, press

The display will indicate "Func".

2. Press the key. The display will indicate "ASLEEP".

3. If the instrument displays "ASLEEP", press one of the following keys to return to the Weigh Mode:



5.6 Setpoints



A. Introduction

1. Hardware Requirements

Operation of setpoints require accessories 5810, 5800 and 5804 (Quad Setpoint) or 584 (Dual Setpoint) to be installed.

NOTE

Only the "Grading Scale" mode does not require these accessories.

2. Service Programming Requirements

At the time of installation, one of 9 options (setpoints) listed below must be selected at program step 14. Setpoint function for each of the options is contained in Subsection 5.6.

Programming Step 14 (Setpoints)			
Subsection	Code	Option	
	0	Disable All Setpoint Operations	
5.7.A.1	1	Acc 584 Independent Setpoints, Zero Start	
5.7.A.2	2	Acc 584 Independent Setpoints, Zero End	
5.7.B.1	3	Acc 584 Paired Setpoints, Zero Start	
5.7.B.2	4	Acc 584 Paired Setpoints, Zero End	
5.6	5	Grading Scale	
5.7.B.1	6	Acc 5804 Paired Setpoints, Zero Start	
5.7.B.2	7	Acc 5804 Paired Setpoints, Zero End	
5.7.A.1	8	Acc 5804 Independent Setpoints, Zero Start	
5.7.A.2	9	Acc 5804 Independent Setpoints, Zero End	

3. Setpoint Programming

In addition to the service programming above, each setpoint must be assigned a weight value. Negative weight values cannot be used. For Setpoint Programming, refer to part B of this Subsection.

4. Grading Scale Programming

For Grading Scale Programming, refer to Subsection 6.9.

5.6.1 Setpoint Programming

The Setpoint Programming Mode is used to assign weight values to the individual setpoints, view the setpoint values, or disable individual setpoints.

A setpoint is enabled when the setpoint is selected by the operator during programming. If a setpoint has been disabled, that setpoint will not appear as an option in the

STOP

key menu, see Setpoint operation.

Programming of setpoints requires the operator to select the setpoint to be programmed, then assign a weight value to that setpoint. The weight assigned must be in the same weight units as were displayed prior to entering the programming mode. Knowledge of the operating mode selected in instrument programming step 14 is required to ensure the appropriate weight is being assigned to the setpoint. Refer to Subsection 5.6, Setpoint Operation, for a description of operating modes.

- Press **FUNC** and **1 SET PT** keys and the display will show "SET".

- Press the **0** key to return the instrument to the weighing mode.
- Select Setpoints 1, 2, 3, or 4 using the numeric keypad.

- The selected setpoint may be disabled by pressing the **0** key. The disable legend will appear.

- Press the **ENTER** key to view the selected setpoint value.

- Press any key and "ALtEr" will be displayed.

- Press the **ENTER** key to save the current setpoint value. The instrument will return to the weighing mode.

- A new value may be entered using the numeric keypad. The new value will be displayed. Press the **ENTER** key to save the new value. The instrument will return to the weighing mode. To correct entry errors, press **0** until a single zero is displayed.

5.7 Grading Scale

FUNC **1 SET PT**

The Grading Scale option must be selected in Service Program Step 14. The weight assigned must be in the same weight units as were displayed prior to entering the programming mode.

Place the instrument into the Weigh Mode.

- Press **FUNC**, **1 SET PT** keys "GrAdE" will be displayed.

- The operator must choose to view the "UNDER" range value or the "OVER" range value or exit to the Weigh Mode.

- Press **1 SET PT** and **ENTER** to view the "under" range value.

- Press **2 SLEEP** and **ENTER** to view the "over" range value.

- Press **3** or **4 TIME** to exit to the Weigh Mode.

- Press any key and "ALtEr" will be displayed.

- a. Press **ENTER** to save the current value.
- b. A new value may be entered using the numeric keypad. The new value will be displayed. Press the **ENTER** key to save the new value. The instrument will return to the weighing mode. To correct entry errors, press **0** until a single zero is displayed.

4. The instrument will then return to the Weigh Mode.

5.8 Printer Output Channel A



In addition to I/O Output Accessory #5805 being installed in the instrument, Accessories 5806, 5807, and 5808 must be installed and Channel A must be enabled at Service Program Step 15.

1. Place the instrument into the weighing mode.
2. Press **FUNC**. "FunC" will be displayed.
3. Press **7 PROG** and the display will show "CuSt".
4. Press **PRINT** key and the display will show "Chan".
 - a. Press **ENTER** to return to the Weigh mode.
 - b. Press **PRINT** and "Chan A" is displayed.
5. With "Chan A" prompt displayed, press the **ENTER** key. The display will show the Channel A baud rate.

NOTE
Do not set a baud rate of 19200 on one channel and 38400 for another. Any other combination is acceptable.

Set the Output Format as listed in the following chart.

The **PRINT** key toggles the operator through the available options. The **ENTER** key saves the displayed options and advances to the next parameter.

Programming Chart, Channel A

Baud Rate Options	
Displayed Options	
300	
600	
1200	
2400	For Fairbanks Models 3710, 3920, 3921 and 3925 Printers
4800	
9600	
19200	
38400	
Stop Bits Options	
Displayed Options	
Stop 1	For Fairbanks Models 3710, 3920, 3921 and 3925 Printers
Stop 2	
Parity Options	
Displayed Options	
EuEn	
Odd	For Fairbanks Models 3920, 3921 and 3925 Printers
nonE	For Fairbanks Model 3710 Printer
Character Data Bits Options	
Displayed Options	
Char 7 (7 bit character)	For Fairbank Models 3925 Printer
Char 8 (8 bit character)	For Fairbanks Models 3710, 3920 and 3921 Printers
Time/Date/ID Output Format Options	
Displayed Options	
no tdi	Time, date and ID will not be printed.
t	Time only is printed
d	Date only is printed
td	Both time and date are printed
i	ID only is printed
ti	Both time and ID are printed
d i	Both date and ID are printed
tdi	Time, date and ID are printed
Net Output FormatOptions	
Displayed Options	
9nt	Gross/Net/Tare Weights are enabled to be printed when in the Net Weighing Mode
nEt	Net Weigh only is enabled to be printed when in the Net Weighing Mode

Line Terminator Options	
Displayed Options CrLF	A carriage return and line feed will be inserted at the end of each data string
Cr	A carriage return will be inserted at the end of each data string

7. Instrument returns to the Weigh Mode.

5.9 Computer/Remote Display Output (Channel B)

NOTE

In order for Channel B to be enabled, Program Step #15 must be 2 or 3.

- Place the instrument into the weighing mode.
- Press **FUNC**. "FunC" will be displayed.
- Press **7** **PROG** and the display will show "CuSt".
- Press **PRINT** key and the display will show "Chan".
 - Press **ENTER** to return to the Weigh mode.
 - Press **PRINT** and "Chan A" is displayed. Pressing **PRINT** toggles between Channel A and Channel B
- With "Chan B" prompt displayed, press the **ENTER** key. The baud rate for Channel B will be displayed.
- Set the Output Format from the following chart. The **PRINT** key toggles through the options. The **ENTER** key saves the displayed options and advances to the next parameter.

Programming Chart, Channel B

Baud Rate Options	
Displayed Options	
300	
600	
1200	
2400	
4800	
9600	
19200	
38400	
Stop Bits Options	
Displayed Options	
Stop 1	
Stop 2	
Parity Options	
Displayed Options	
EuEn	
odd	
nonE	
Character Data Bits Options	
Displayed Options	
Char 7 (7 bit character)	
Char 8 (8 bit character)	
Device Type Options	
Displayed Options	
Putr	Selects computer output protocol. Following this selection, the current computer output format selection will be displayed.
diSPLA	Selects output protocol for Fairbanks remote displays. Following this selection, the instrument will return to the Weigh mode.

If "Putr" was selected:

Computer Output Format Options	
Displayed Options	
Cont	Weight data is transmitted continuously at the display update rate programmed. Following this selection, the instrument will return to the Weigh mode.
PoLLEd	Weight data is transmitted only when requested. Following this selection, the instrument will display the current Polling Format.

If "PoLLEd" was selected:

Polling Format Options	
Displayed Options	
Cr	Weight data is transmitted when the instrument receives a carriage return
Crld	Weight data is transmitted when the instrument receives an "ID" followed by a carriage return. The "ID" must be programmed in Program Step 12.

5.10 Analog Output (4-20mA)



The 4-20mA analog output requires Accessory 5810 (Smart 4-20) and Service Program Step 13 enabled. The information programmed at Step 13 determines if the output current is directly (current increases with weight increase) or inversely (current decreases with weight increase) proportional to the weight on the platform. The weight assigned must be in the same weight units as were displayed prior to entering the programming mode.

The output can be driven by one of the following:

1. Gross Weight:

In this mode the output current is proportional to the Gross weight. The 4-20mA output remains proportional to the Gross weight even when Net weight is being displayed.

2. Net Weight:

In this mode the output current is proportional to the Net weight. The absolute value of the Net weight is used, the sign is ignored. The 4-20mA output remains proportional to the Net weight even when Gross weight is being displayed.

3. A/D Counts Output:

In this mode the output current is proportional to the weight on the platform expressed as A/D counts. The A/D Counts Output Mode can only be directly proportional to the weight on the platform.

The Accessory 5810 can resolve a minimum increment of 6 microamps at a resolution of 1 in 4096. The maximum source compliance voltage is + 40VDC. The Accessory 5810's output is a 24 milliamp current sink referenced to ground.

When the instrument is not in a weighing mode, the 4-20mA output will stop responding at the value just prior to exiting the weighing mode and will not respond to weight changes on the platform.

The design of the Accessory 5810 will never allow the output current to exceed 24mA or be less than 0mA. If the instrument is out of the weighing range, over or under, the output current will be 24mA.

5.10.14-20mA Analog Output Current Calibration For Gross Or Net Mode

To calibrate the current output values, the current output must be monitored with a milliammeter. The precision of the calibration depends on the accuracy and resolution of the monitoring device.

For equipment protection, any control equipment driven by the Accessory 5810 must be disconnected or in some way disabled during calibration.

1. Press . The display will show "FunC".
2. Press the key. The display shows "CuSt".
3. Press the key. The display will then show "AnA-Log".
- 4a. Press to return to the Weigh mode.
- 4b. Press the key. "HiLoop" is displayed. Repeatedly pressing will toggle the display between "HiLoop" and "LoLoop".





The Accessory 5810 Analog Output needs two calibration points to define the operation range. The calibration points need to be separated by the widest range possible to obtain the maximum accuracy. "LoLoop" is the calibration procedure for assigning the lower current calibration weight value. "HiLoop" is the calibration procedure for assigning the upper current calibration weight value.

5. When the desired prompt is displayed, press . The display will show a number between 0 and 4095.
6. Look at the milliammeter reading and establish whether the current must be increased or decreased from its present value to achieve the desired calibration value.

To decrease the output current, use keys 1, 4 and 7. To increase the output current, use keys 3, 6 and 9.

Refer to the following chart:

Key	Instrument Display/Milliammeter
Decreasing	
1	Decreases by 1, the displayed number. Current decreases by 6 microamps.
4	Decreases by 10, the displayed number. Current decreases by 60 microamps.
7	Decreases by 100, the displayed number. Current decreases by 600 microamps.
Increasing	
3	Increases by 1, the displayed number. Current increases by 6 microamps.
6	Increases by 10, the displayed number. Current increases by 60 microamps.
9	Increases by 100, the displayed number. Current increases by 600 microamps.

7. When the milliammeter shows the calibration value, press . The previously programmed calibration weight will be displayed.
8. Press any key and "ALtEr" will be displayed.
9. To keep the previous calibration value, press . To change the value, use the keypad to enter a new weight and press . The instrument will then return to the weighing mode. To correct entry errors, press the  key until a single "0" is displayed.

NOTE

Remember to calibrate both "HiLoop" and "LoLoop".






5.10.24-20mA Analog Output Current Calibration For A/D Counts Mode

To calibrate the current output values, the current output must be monitored with a milliammeter. The precision of the calibration depends on the accuracy and resolution of the monitoring device.


For equipment protection, any control equipment driven by the Accessory 5810 must be disconnected or in some way disabled during calibration.

1. Place the calibration weight on the platform. This is the weight that will be assigned to the "HiLoop" or "LoLoop" programmed current.

2. Press . The display will show "FunC".

3. Press the  key. The display shows "CuSt".
4. Press the  key. The display will then show "AnA-Log".
 - a. Press  to return to the Weigh mode.
 - b. Press the  key. "HiLoop" is displayed. Repeatedly pressing  will toggle the display between "HiLoop" and "LoLoop".

The Accessory 5810 Analog Output needs two calibration points to define the operation range. The calibration points need to be separated by the widest range possible to obtain the maximum accuracy. "LoLoop" is the calibration procedure for assigning the lower current calibration weight value. "HiLoop" is the calibration procedure for assigning the upper current calibration weight value.

5. When the desired prompt is displayed, press . The display will show a number between 0 and 4095.
6. Look at the milliammeter reading and establish whether the current must be increased or decreased from its present value to achieve the desired calibration value.

To decrease the output current, use keys 1, 4 and 7.

To increase the output current, use keys 3, 6 and 9. Refer to the following chart:

Key	Instrument Display/Milliammeter
Decreasing	
1	Decreases by 1, the displayed number. Current decreases by 6 microamps.
4	Decreases by 10, the displayed number. Current decreases by 60 microamps.
7	Decreases by 100, the displayed number. Current decreases by 600 microamps.
Increasing	
3	Increases by 1, the displayed number. Current increases by 6 microamps.
6	Increases by 10, the displayed number. Current increases by 60 microamps.
9	Increases by 100, the displayed number. Current increases by 600 microamps.

7. When the milliampmeter shows the calibration value, press .
8. The display will show the A/D counts related to the weight on the platform. Press the key to complete the calibration and the instrument will return to the weigh mode.

NOTE

Remember to calibrate both "HiLoop" and "LoLoop".

SECTION 6: CUSTOMER/OPERATOR SERVICE

6.1 Basic Maintenance and Troubleshooting

A. Introduction

This Section describes Basic Customer Maintenance and Troubleshooting Procedures. Tampering with the service seal or attempting to open the Instrument Enclosure may expose dangerous electrical voltage. Adjustments and modifications require the services of a Fairbanks Trained Technician.

B. Basic Maintenance

1. Cleaning

The instrument cabinet may be washed down with low pressure water and mild cleaning solutions.

Avoid the use of abrasive cleansers or chemical solvents which may scratch or mar the enclosure surface and display window.

2. Lubrication Restriction

Do not attempt to lubricate any parts of this equipment.

C. Basic Troubleshooting

In case of malfunction, the operator should check the following chart for problems and suggested remedies before contacting Fairbanks Service.

A. No Display

1. Batteries discharged: Recharge
2. Battery disconnected at rear panel: Reconnect

B. Display Segment(s) Fail TEST

1. Contact Fairbanks Service for repair.

C. Key Does Not Zero Display

1. Instrument is in other than GROSS or NET Mode: Press MODE/on to select Gross.
2. Load receiver in motion: Remove source of vibration or motion.
3. Weight outside programmed zero range.

D. Incorrect Weight

1. Incorrect procedure: Review Procedures.
2. Net Weight error can result if Tare in memory is not correct: Make certain correct Tare is in memory.
3. Faulty Load Receiver: Contact Fairbanks Service.

E. Display Locked-up or Inoperative

1. Unplug connectors at J2 and J3 at the Instrument Rear Panel. Reconnect after approximately 20 seconds. If display is still inoperative then repeat the above.
2. Faulty Instrument: Contact Fairbanks Service.

F. Recharge Legend Lighted

1. Battery should be recharged: Remove battery to safe area for recharging.
2. LoBatt Legend: Battery must be recharged.

6.2 Periodic Inspection Procedures


This Section describes inspection procedures which should be performed at periodic intervals such as required for units covered by Maintenance Contracts or Service Agreement.




These instructions apply only to the Instrument; inspection procedures for Load Receiver and any Accessories are given in Manuals applicable to the particular unit.

A. Physical Inspection

Check that all cable connections are secure.

B. Built-in Tests

The  key is used to enable the operator to check each of the display segments and operator legend prompts for proper operation.

1. Select the Gross or Net Mode.
2. Push the  key then the  key
3. Instrument will display in the following sequence when the  key is pushed:
 - a. Displays internal counts equal to weight on platform
 - b. Program revision
 - c. All segments and legends

d. Instrument will return to the Gross or Net Mode

6.3 Battery Packs 575 and 575D

Each battery pack consists of four 2 volt cell. The cells are grouped into two 4 volts sections, with a total nominal output of 8 volts. The H90-3051 and H90-3052 indicators will show a re-charge legend when the battery pack voltage drops to 7.75 volts, and will turn OFF when the level drops to 7 volts.

The battery pack should be placed on the "Smart" charger as soon as the indicator displays the "recharge" or "Lo bAtt" legend.

If the indicator turns "OFF", because of low battery voltage, the battery voltage should be checked before it is put on the "Smart" charger.


OPEN CIRCUIT VOLTAGE - The DC voltage, measured between pins 1 and 2 on the connector on the Accessory 575, 575D battery, when disconnected from the indicator.

1. If the **OPEN CIRCUIT VOLTAGE (OCV)** is 6.6 volts or greater, the battery pack is good and can be re-charged.
 2. If the OCV is 6.4 volts or less, at least one of the four cells is internally shorted and the charger will be damaged if connected to the battery pack. **REPLACE THE BATTERY PACK.**
-

APPENDIX I: CONTROL DRAWING

7-18-96

LOW POWER INSTRUMENT H90-3051




NO.	DATE	DESCRIPTION	BY	CHKD	DATE
1	7-18-96	ISSUED	GA		4-1-96
A	7-18-96	REVISED	GA		5-1-96
B	7-18-96	REVISED	GA		5-1-96
C	7-18-96	REVISED	GA		5-1-96
D	7-18-96	REVISED	GA		5-1-96
E	7-18-96	REVISED	GA		5-1-96
F	7-18-96	REVISED	GA		5-1-96
G	7-18-96	REVISED	GA		5-1-96
H	7-18-96	REVISED	GA		5-1-96
I	7-18-96	REVISED	GA		5-1-96

No change may be made to this drawing or related components without prior written approval from Factory Mutual!!!

DR: ORCAD/MPD DATE: 9-18-94 CR: MPD APP: MPD	C5606011 Fairbanks Scales St. Johnsbury, Vermont
NEXT ASSY 3-56062-1	FM APPROVED LOW POWER INDICATORS FOR USE IN HAZARDOUS LOCATIONS
3-56060 3-56060	1 of 4




REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED
-	RELEASED	11-1-90	MPD
A	REV PER ECO 11395	GDL 5-21-90	MPD

CABLE ACCESSORY NO. 576
INSTRUMENT END



OR

CABLE ACCESSORY NO. 576
INSTRUMENT END



DATE		DATE	
DR	CH	DATE	DATE
APP			
THE MATERIAL AND INFORMATION CONTAINED HEREIN IS CONFIDENTIAL AND IS THE PROPERTY OF FAIRBANKS SCALES, AND IS NOT TO BE REPRODUCED, COPIED, TRANSFERRED OR REPRODUCED WITHOUT THE PRIOR WRITTEN PERMISSION OF FAIRBANKS.		FAIRBANKS SCALES, INC. (MTRIC) DIMENSIONS AND UNITS: DIMENSIONS: FRACTIONS + TOLERANCES: DECIMALS + ANGLES: DECIMALS + PLACES DECIMALS +	
MATERIAL		FINISH	
NEXT ASSY.		USED ON	
APPLICATION			
HAZARDOUS AREA		SAFE AREA	
Fairbanks Scales St. Johnsbury, Vermont		FM APPROVED LOW POWER WEIGHT INDICATOR FOR USE IN HAZARDOUS LOCATIONS	
SIZE	DRAWING NO.	SCALE	SHEET
C	3-56060	NONE	2

REVISED	DATE	BY	REVISION
B	1-17-80	MPD	REVISED
C	3-24-82	MPD	ADDED NEW CELLS ADDED NEW AVERY ADDED NEW AVERY ADDED NEW AVERY
D	11-18-82	MPD	ADDED NEW CELLS ADDED NEW AVERY ADDED NEW AVERY ADDED NEW AVERY
E	1-17-82	MPD	ADDED NEW CELLS ADDED NEW AVERY ADDED NEW AVERY ADDED NEW AVERY
F	1-17-82	MPD	ADDED NEW CELLS ADDED NEW AVERY ADDED NEW AVERY ADDED NEW AVERY
G	1-17-82	MPD	ADDED NEW CELLS ADDED NEW AVERY ADDED NEW AVERY ADDED NEW AVERY
H	8-21-82	MPD	ADDED NEW CELLS ADDED NEW AVERY ADDED NEW AVERY ADDED NEW AVERY
I	1-22-87	SAL	ADDED NEW CELLS ADDED NEW AVERY ADDED NEW AVERY ADDED NEW AVERY

7-18-96

MANUFACTURER

- SI-LODEC
- 83-00360-10
 - 83-00370-10
 - 83-00270-10
 - 83-00420-10
 - 83-00420-11
 - 83-00460-10
 - 83-00490-10
 - 83-00500-10
 - 83-00505-10
 - 83-00520-10
 - 83-00520-12
 - 83-00520-13
 - 83-00525-12
 - 83-00530-10
 - 83-00540-10
 - 83-00550-10
 - 83-00550-20
 - 83-00600-10
 - 83-00600-13
 - 83-00610-10
 - 83-00610-13
 - 83-00615-10
 - 83-00625-10
 - 83-00635-10
 - 83-00755-10
 - 83-00755-15
 - 83-00800-10

C5606013

Fairbanks Scales
Subsidiary, Vermont

FOR APPROVED LOW POWER INDICATORS
FOR USE IN HAZARDOUS LOCATIONS

FAIRBANKS INC. 3-56050

MEET '87

LOAD CELL MANUFACTURER	MANUFACTURER PART NUMBER	FWD PLATFORM (for reference only)
FAIRBANKS	3-53776-1	H23-2511 & 23-2511 70-4070 70-4170
	3-54723-1	21-2102 & 21-2104 21-2101
	3-54824-1	H70-4814 H70-4820
	3-54824-2	
	3-55122-1	
	3-55157-1	
	3-55178-1	
	3-55177-1	
	3-55383-1	

H80-9104

REVERE TRANSDUCERS INCORPORATED

- SSB FAMILY
- SSB-10-30-ST398 FAMILY
- USP FAMILY
- CBU1 FAMILY
- UPF FAMILY
- LT01 FAMILY
- LPC1 FAMILY
- KB FAMILY
- CSP FAMILY
- CP FAMILY
- UMP FAMILY
- UEP FAMILY
- UES FAMILY
- TSP FAMILY
- HSP FAMILY
- USPF FAMILY

FLINTAB

HBM INC. (HAWAIIAN MANUFACTURING CO.)

- SB2 FAMILY
- SB3 FAMILY
- BBS FAMILY
- SUF FAMILY
- UIT FAMILY
- TLC FAMILY
- USB FAMILY
- PLC FAMILY
- ALC FAMILY
- BLF FAMILY
- TRT FAMILY
- JRT FAMILY
- THC FAMILY
- HLC FAMILY
- RSC FAMILY
- PW2C3 FAMILY
- PW2-2 FAMILY
- LCB FAMILY
- PWS FAMILY

GSE SCALE SYSTEMS 4515 PLATFORMS

LOAD CELL MANUFACTURER	MANUFACTURER PART NUMBER	FWD PLATFORM (for reference only)
SENSORTRONICS	60001 FAMILY	1106 &
	60001-500	1170
	60001-750	1107
	60001-1K	1108
	60001-1.5K	609-5400
	60001-2K	1109
	60001-3K	1111
	60001-5K	1112
	60008 FAMILY	
	60018 FAMILY	
	60030 FAMILY	
	60036 FAMILY	
	60040 FAMILY	
	60045 FAMILY	
	60048 FAMILY	
	60051 FAMILY	
	60058 FAMILY	
	60060 FAMILY	
	65016 FAMILY	
	65016-5K	80-9114
	65016-15K	80-9118
	65016-25K	80-9108
	65016-50K	80-9110
	65016-0104-15K	80-9119
	65016-0104-25K	80-9109
	65023 FAMILY	
	65023-2.5K-1107	23-2554AFM
	65023A-2.5K	H70-4100AFM
	65023A-2.5K-0140	H23-2502FM
	65023A-2.5K-0140	H23-2500AFM
	65023A-2.5K-1107	23-2502AFM
	65023A-2.5K-0140	23-2500AFM
	65023A-1K-5140	H70-4100BFM
	65023A-5K-0140	H23-2512FM
	65023A-5K-0140	H23-2503AFM
	65023A-5K-0140	23-2557
	65023A-10K-0140	23-2558
	65024 FAMILY	
	65029 FAMILY	
	65032 FAMILY	
	65041 FAMILY	
	65058 FAMILY	
	65059 FAMILY	
	65059-75	80-9016
	65059-100	80-9111
	65059-250	80-9117
	65059-500	80-9112
	65059-1K	80-9113
	65061 FAMILY	
	65063 FAMILY	
	65094 FAMILY	

TEDEA-HUNTLEIGH 1000 SERIES 3400 SERIES 9010 SERIES

GEC AVERY 8701 FAMILY 8707 FAMILY 8708 FAMILY 8713 FAMILY T101 FAMILY T103 FAMILY T105 FAMILY

No change may be made to this drawing or related components without prior written approval from Factory Mutual!!!


ORCAD/MPD

MPD


The enclosed and information contained herein is confidential and is the property of Fairbanks Scales. It is to be used solely for the purpose of the purchase of Fairbanks Scales.

REVISIONS		DATE	CONTRNO
1	ISSUE	11/14/81	MPD
2	REVISION	03/25/82	MPD
3	REVISION	03/25/82	MPD

LOW POWER INSTRUMENT H90-3051



LOW POWER INSTRUMENT H90-3051



NO CHANGE MAY BE MADE TO THIS DRAWING OR RELATED COMPONENTS WITHOUT PRIOR WRITTEN APPROVAL FROM THE CANADIAN STANDARDS ASSOCIATION

C56060C4

Fairbanks Scales
300 UNIVERSITY AVENUE
FAIRBANKS, ALASKA

FM APPROVED LOW POWER FOR USE IN HAZARDOUS LOCATIONS

3-56060

DESIGNED BY	ORCAD/MPD
DRAWN BY	MPD
CHECKED BY	MPD

The material and information contained herein is confidential to the engineering department of Fairbanks Inc. and is not to be used, disclosed, copied, transferred or reproduced without the prior written permission of Fairbanks.

HAZARDOUS AREA
CLASS I, GROUPS C & D
CLASS II, GROUPS E, F & G
CLASS III

APPENDIX II: ASCII CHARACTER TO NUMERIC VALUES

Decimal	Octal	Hex	ASCII	B7	B6	B5	B4	B3	B2	B1	Decimal	Octal	Hex	ASCII	B7	B6	B5	B4	B3	B2	B1
0	000	00	NUL	0	0	0	0	0	0	0	74	112	4A	J	1	0	0	1	0	1	0
10	012	0A	LF	0	0	0	1	0	1	0	75	113	4B	K	1	0	0	1	0	1	1
11	013	0B	VT	0	0	0	1	0	1	1	76	114	4C	L	1	0	0	1	1	0	0
12	014	0C	FF	0	0	0	1	1	0	0	77	115	4D	M	1	0	0	1	1	0	1
13	015	0D	CR	0	0	0	1	1	0	1	78	116	4E	N	1	0	0	1	1	1	0
14	016	0E	SO	0	0	0	1	1	1	0	79	117	4F	O	1	0	0	1	1	1	1
15	017	0F	SI	0	0	0	1	1	1	1	80	120	50	P	1	0	1	0	0	0	0
27	033	1B	ESC	0	0	1	1	0	1	1	81	121	51	Q	1	0	1	0	0	0	1
28	034	1C	FS	0	0	1	1	1	0	0	82	122	52	R	1	0	1	0	0	1	0
29	035	1D	GS	0	0	1	1	1	0	1	83	123	53	S	1	0	1	0	0	1	1
30	036	1E	RS	0	0	1	1	1	1	0	84	124	54	T	1	0	1	0	1	0	0
31	037	1F	US	0	0	1	1	1	1	1	85	125	55	U	1	0	1	0	1	0	1
32	040	20	SP	0	1	0	0	0	0	0	86	126	56	V	1	0	1	0	1	1	0
33	041	21	!	0	1	0	0	0	0	1	87	127	57	W	1	0	1	0	1	1	1
34	042	22	"	0	1	0	0	0	1	0	88	130	58	X	1	0	1	1	0	0	0
35	043	23	#	0	1	0	0	0	1	1	89	131	59	Y	1	0	1	1	0	0	1
36	044	24	\$	0	1	0	0	1	0	0	90	132	5A	Z	1	0	1	1	0	1	0
37	045	25	%	0	1	0	0	1	0	1	91	133	5B	[1	0	1	1	0	1	1
38	046	26	&	0	1	0	0	1	1	0	92	134	5C	\	1	0	1	1	1	0	0
39	047	27	'	0	1	0	0	1	1	1	93	135	5D]	1	0	1	1	1	0	1
40	050	28	(0	1	0	1	0	0	0	94	136	5E	^	1	0	1	1	1	1	0
41	051	29)	0	1	0	1	0	0	1	95	137	5F	_	1	0	1	1	1	1	1
42	052	2a	*	0	1	0	1	0	1	0	96	140	60	`	1	1	0	0	0	0	0
43	053	2b	+	0	1	0	1	0	1	1	97	141	61	a	1	1	0	0	0	0	1
44	054	2C	,	0	1	0	1	1	0	0	98	142	62	b	1	1	0	0	0	1	0
45	055	2D	-	0	1	0	1	1	0	1	99	143	63	c	1	1	0	0	0	1	1
46	056	2E	.	0	1	0	1	1	1	0	100	144	64	d	1	1	0	0	1	0	0
47	057	2F	/	0	1	0	1	1	1	1	101	145	65	e	1	1	0	0	1	0	1
48	060	30	0	0	1	1	0	0	0	0	102	146	66	f	1	1	0	0	1	1	0
49	061	31	1	0	1	1	0	0	0	1	103	147	67	g	1	1	0	0	1	1	1
50	062	32	2	0	1	1	0	0	1	0	104	150	68	h	1	1	0	1	0	0	0
51	063	33	3	0	1	1	0	0	1	1	105	151	69	i	1	1	0	1	0	0	1
52	064	34	4	0	1	1	0	1	0	0	106	152	6A	j	1	1	0	1	0	1	0
53	065	35	5	0	1	1	0	1	0	1	107	153	6B	k	1	1	0	1	0	1	1
54	066	36	6	0	1	1	0	1	1	0	108	154	6C	l	1	1	0	1	1	0	0
55	067	37	7	0	1	1	0	1	1	1	109	155	6D	m	1	1	0	1	1	0	1
56	070	38	8	0	1	1	1	0	0	0	110	156	6E	n	1	1	0	1	1	1	0
57	071	39	9	0	1	1	1	0	0	1	111	157	6F	o	1	1	0	1	1	1	1
58	072	3A	:	0	1	1	1	0	1	0	112	160	70	p	1	1	1	0	0	0	0
59	073	3B	;	0	1	1	1	0	1	1	113	161	71	q	1	1	1	0	0	0	1
60	074	3C	<	0	1	1	1	1	0	0	114	162	72	r	1	1	1	0	0	1	0
61	075	3D	=	0	1	1	1	1	0	1	115	163	73	s	1	1	1	0	0	1	1
62	076	3E	>	0	1	1	1	1	1	0	116	164	74	t	1	1	1	0	1	0	0
63	077	3F	?	0	1	1	1	1	1	1	117	165	75	u	1	1	1	0	1	0	1
64	100	40	@	1	0	0	0	0	0	0	118	166	76	v	1	1	1	0	1	1	0
65	101	41	A	1	0	0	0	0	0	1	119	167	77	w	1	1	1	0	1	1	1
66	102	42	B	1	0	0	0	0	1	0	120	170	78	x	1	1	1	1	0	0	0
67	103	43	C	1	0	0	0	0	1	1	121	171	79	y	1	1	1	1	0	0	1
68	104	44	D	1	0	0	0	1	0	0	122	172	7A	z	1	1	1	1	0	1	0
69	105	45	E	1	0	0	0	1	0	1	123	173	7B	{	1	1	1	1	0	1	1
70	106	46	F	1	0	0	0	1	1	0	124	174	7C		1	1	1	1	1	0	0
71	107	47	G	1	0	0	0	1	1	1	125	175	7D	}	1	1	1	1	1	0	1
72	110	48	H	1	0	0	1	0	0	0	126	176	7E	~	1	1	1	1	1	1	0
73	111	49	I	1	0	0	1	0	0	1	127	177	7F	DEL							

APPENDIX III: OUTPUT FORMATS

Typical Channel A, Printer Output

```

2000 1b   GR
03:02 PM
4- 9-91
0
    
```

GROSS MODE

```

2000 1b   GR
1000 1b   TA
1000 1b   NT
03:02 PM
4- 9-91
0
    
```

NET MODE

```

1999 1b   GR
5000 1b   TA
1b        NT
03:03 PM
4- 9-91
0
    
```

NET MODE with NEGATIVE NET

```

1b        GR
1999 1b   TA
1b        NT
03:04 PM
4- 9-91
0
    
```

NET MODE, NEGATIVE GROSS and NET

```

1b        GR
03:04 PM
4- 9-91
0
    
```

GROSS MODE, NEGATIVE GROSS 2494

Remote Display

1. 20mA current loop set-up

```

Baud Rate       : Programmable
Stop Bits       : Programmable
Parity          : Programmable
Character Data Bits : Programmable
    
```

2. Output Format

Character #	Description
1	STX (Start of Text Character)
2 and 3	2 character ID, data field defined as follows: Calibration Units Gross Weight = 40 Calibration Units Net Weight = 41 Alternate Units Gross Weight = 43 Alternate Units Net Weight = 44
4 through 10	7 character, weight data field, characters 0 through 9, decimal point and minus sign. The minus sign will always appear in the first character location. Leading zeroes are blanked. Overcapacity is transmitted as a string of minus signs.
11	ETX (End of Text Character)

Computer Output

1. RS232 Channel set-up

```

Baud Rate       : Programmable
Stop Bits       : Programmable
Parity          : Programmable
Character Data Bits : Programmable
    
```

2. Output format for all set-ups, ie. continuous or polled.

Description in order of transmission	
1	6 to 7 character weight data field, characters 0 through 9, decimal point and minus sign. The minus sign will appear in the first character location. Leading zeros are blank
2	Space
3	5 character units legend data field: lb, kg, g, oz, tonne. Left justified and the trailing zeros are blank.
4	Space
5	2 character weighing mode data field, GR (Gross), NT (Net). Lower case characters are transmitted if the scale is in motion.
6	Carridge return
7	Line feed, programmable

APPENDIX IV: CANADIAN STANDARD ASSOCIATION APPROVED INSTRUMENTS

Models H90-3051C1 through C4 are Canadian instruments. Each model has accessories installed at the factory.

H90-3051C1	No input/output accessories
H90-3051C2	Accessory 5810 (SMART 4/20mA Analog Current Output) installed
H90-3051C3	Accessory 5805 (Serial Communications Assembly) installed
H90-3051C4	Accessories 5810 and 5805 installed

10-13-95


LOW POWER INSTRUMENT H90-3051Cx

H90-3051C1 - NO INPUT/OUTPUT ACCESSORIES

H90-3051C2 - ACCESSORY 5810

H90-3051C3 - ACCESSORY 5805

H90-3051C4 - ACCESSORIES 5810 AND 5805





NO CHANGE MAY BE MADE TO THIS DRAWING OR RELATED COMPONENTS WITHOUT PRIOR WRITTEN APPROVAL FROM THE CANADIAN STANDARDS ASSOCIATION

CLASS I, GROUPS A, B, C & D
CLASS II, GROUPS E, F & G
CLASS III

INSTALLATION NOTICE: ANY CABLING CONNECTED TO THE INSTRUMENT MUST HAVE SUFFICIENT SLACK TO ENABLE THE INSTRUMENT TO BE CALIBRATED AND PROPER OPERATION VERIFIED WHILE THE INSTRUMENT IS RESTING ON A CONVENIENT SURFACE SUCH AS A TABLE TOP, WORKBENCH OR FLOOR. SEE SH4437 (ATTACHED TO INSTRUMENT).


CAD/GDL		C57481A1	
DR	MPD	Fairbanks Scales	
MP	MPD	CSA CERTIFICATION DRAWING FOR LOW POWER WEIGHT INDICATOR FOR USE IN HAZARDOUS LOCATIONS	
SIZE	C	DRAWING NO.	3-57481
SCALE		SHEET	1/3

REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED
-	RELEASED	11-1-91	MPD



THE USER OBTAINING SPECIFIED DIMENSIONS AND TOLERANCES IN FRACTIONS + PLACES DECIMALS + PLACES DECIMALS +		DR. _____ CH. _____ APP. _____	DATE _____
MATERIAL _____ FINISH _____		THE MATERIAL AND INFORMATION CONTAINED HEREIN IS CONFIDENTIAL AND IS THE PROPERTY OF FAIRBANKS SCALES, AND IS NOT TO BE USED, REPRODUCED, TRANSMITTED, OR REPRODUCED WITHOUT THE PRIOR WRITTEN PERMISSION OF FAIRBANKS.	
NEXT ASSY. _____	USED ON _____	FAIRBANKS Scales St. Johnsbury, Vermont	
APPLICATION _____		CSA CERTIFICATION DRAWING FOR LOW POWER WEIGHT INDICATOR FOR USE IN HAZARDOUS LOCATIONS	DRAWING NO. 3-57481
HAZARDOUS AREA		SAFE AREA	SCALE NONE SHEET 2 OF 3

LOW POWER INSTRUMENT H90-3051Cx
H90-3051C1 - NO INPUT/OUTPUT ACCESSORIES
H90-3051C3 - ACCESSORY 5805



HAZARDOUS AREA
CLASS I, GROUPS C & D
CLASS II, GROUPS E, F & G
CLASS III

NO CHANGE MAY BE MADE TO THIS DRAWING OR RELATED COMPONENTS WITHOUT PRIOR WRITTEN APPROVAL FROM THE CANADIAN STANDARDS ASSOCIATION

INSTALLATION NOTICE: ANY CABLING CONNECTED TO THE INSTRUMENT MUST HAVE SUFFICIENT SLACK TO ENABLE THE INSTRUMENT TO BE CALIBRATED AND PROPER OPERATION VERIFIED WHILE THE INSTRUMENT IS RESTING ON A CONVENIENT SURFACE SUCH AS A TABLE TOP, WORKBENCH OR FLOOR. SEE SI4437 (ATTACHED TO INSTRUMENT).

C57481-3

<p>FAIRBANKS SCALES 1000 WEST 10TH AVENUE DENVER, CO 80202</p>	<p>DATE: 10/13/95 DRAWING NO. 3-57481 SCALE 3/8" = 1"</p>
<p>DESIGNED BY: CAD/GDL CHECKED BY: MPD APPROVED BY: MPD</p>	<p>CSA CERTIFICATION DRAWING FOR LOW POWER WEIGHT INDICATOR FOR USE IN HAZARDOUS LOCATIONS</p>
<p>The manual and information contained herein is confidential and is the property of Fairbanks Scales, a division of Fairbanks Inc. and is not to be used, disclosed, copied, transferred or reproduced without the prior written permission of Fairbanks</p>	

FAIRBANKS S C A L E S

SALES AND SERVICE

For your nearest

Fairbanks Scales

Service Center or Authorized Distributor

Call

1-800-451-4107